



Quality Accessories at a Glance




1 Magnetic motor starter

For thermal overload protection.

2 Air-cooled aftercooler

The factory mounted, heavy duty, air-cooled aftercooler effectively reduces up to 65% of the moisture from discharged compressed air. (select models)



3 Automatic tank drain

Automatically discharges excess moisture from the receiver.

4 Vibration isolator pads

Isolates the compressor unit from the foundation or floor. Reduces noise and protects the unit from any out-of-level floor situation that could cause vibration and damage.



5 Low oil level monitor

Low Oil Level Monitor shuts down the unit when oil levels are below an adequate level. Prevents the unit from restarting if oil levels are not at an adequate level.

6 Dual control

Allows compressor to run in start/stop or continuous run mode. (select models)